

DOCUMENTATION

chamsyslighting.com/genetix-docs



WARRANTY

chamsyslighting.com/pages/warranty



HELP

CUSTOMER SUPPORT

support@chamsys.co.uk

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

This device may not cause harmful interference; and

This device must accept any interference received, including interference that may cause undesired operation.

For more information: <https://www.chamsyslighting.com/pages/fcc-notice>

ChamSys products must be disposed of in accordance with the WEEE disposal and recycling regulations (http://ec.europa.eu/environment/waste/weee/index_en.htm)

WEEE Producer registration number WEE/FF5605UX.



GeNetix

GW21

QUICK START

1 POWER

POWER VIA PoE

The GW21 & GW20 are powered via PoE Mode A (power over the data pair). Wire an Ethernet cable running from the PoE source to the configuration shown below.



NOTE

Only 2 of the 4 total twisted pairs are required when using standard CAT5e cable.

2 UPDATE

FIRMWARE VERSION

This product might be using out of date firmware. Check the latest released version via the online GeNetix documentation.



GeNetix Docs

INSTALL

Firmware updates can be installed via the MagicQ & QuickQ software packages. Download the latest versions below.



MagicQ Download



QuickQ Download