

## DOCUMENTATION

[chamsyslighting.com/genetix-docs](http://chamsyslighting.com/genetix-docs)



## WARRANTY

[chamsyslighting.com/pages/warranty](http://chamsyslighting.com/pages/warranty)



# HELP

## CUSTOMER SUPPORT

[support@chamsys.co.uk](mailto:support@chamsys.co.uk)

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

This device may not cause harmful interference; and

This device must accept any interference received, including interference that may cause undesired operation.

For more information: <https://www.chamsyslighting.com/pages/fcc-notice>

ChamSys products must be disposed of in accordance with the WEEE disposal and recycling regulations ([http://ec.europa.eu/environment/waste/weee/index\\_en.htm](http://ec.europa.eu/environment/waste/weee/index_en.htm))

WEEE Producer registration number WEE/FF5605UX.



GeNetix

# GW20

QUICK START

# 1 POWER

## POWER VIA PoE

The GW21 & GW20 are powered via PoE Mode A (power over the data pair). Wire an Ethernet cable running from the PoE source to the configuration shown below.



## NOTE

Only 2 of the 4 total twisted pairs are required when using standard CAT5e cable.

# 2 UPDATE

## FIRMWARE VERSION

This product might be using out of date firmware. Check the latest released version via the online GeNetix documentation.



GeNetix Docs

## INSTALL

Firmware updates can be installed via the MagicQ & QuickQ software packages. Download the latest versions below.



MagicQ Download



QuickQ Download